



FA1TM FLANGE ALIGNMENT TOOL

Operator Instruction Manual







INDEX

SECTION	CONTENTS	PAGE NO.
1	INTRODUCTION	2
2	SAFETY INFORMATION	2 - 3
3	TECHNICAL DATA	4
	3.1 KIT COMPONENTS	4
	3.2 HOW THE FA1TM WORKS	
4	FLANGE MISALIGNMENT DETERMINATION PROCEDURE	5
	4.1 LATERAL MISALIGNMENT	5
5	FA1TM MECHANICAL FIXED FLANGE AND ROTATIONAL ALIGN-	
	5.1 INSTALLATION AND OPERATION	6 - 7
	5.2 EXAMINATION AND STORAGE	8
	5.3 MAINTAINANCE	8
	5.4 PARTS LIST	9
	5.5 WEIGHTS AND DIMENSIONS	10
	5.6 TROUBLESHOOTING	11
	5.7 APPLICATION DIMENSIONS	11
	5.7 APPLICATION DIMENSIONS	11
6	RANGE OF APPLICATION	
	6.1 BS10, API6BX AND API6B FLANGE TABLES	12
	6.2 ASME B16.5, B16.47 AND DIN WELD NECK FLANGE TABLES	13
	6.3 SPO FLANGE TABLE	14



1. INTRODUCTION

The Equalizer FA1TM TOOL is an aid for use in normal maintenance and installation procedures to enable the realignment of misaligned flanges within their respective working capacities. For example, the tool can be used to assist in the replacement of ring and other types of flange joint. The use of these instructions will promote safe use, and maximize the service life of the tools.

2. SAFETY INFORMATION

The operator MUST read this manual prior to using the tools.

Failure to comply with the following cautions and warnings could cause equipment damage and personal injury; read the manual fully!

Read all the following instructions, warnings and cautions carefully. Follow all safety precautions to avoid personal injury or property damage during system operation.

Equalizer International Ltd cannot be responsible for damage or injury resulting from unsafe product use, lack of maintenance or incorrect product and/or system operation. Contact Equalizer International Ltd when in doubt as to the safety precautions and applications.

Only people competent in the use of mechanical and hydraulic equipment should use these tools.

In all installations the site safety requirements must be adhered to. ALSO the safety of the operator, and when present, any assisting personnel, is of paramount importance along with the safety of others including, when present, the general public.

These instructions are only to cover the safe operation of THE EQUALIZER FA1TM FLANGE ALIGNMENT TOOL, during normal maintenance/installation operations.

All other safety aspects must be controlled by the operation supervisor.



A **CAUTION** is used to indicate correct operating or maintenance procedures and practices to prevent damage to, or destruction of equipment or other property.

A **WARNING** indicates a potential danger that requires correct procedures or practices to avoid personal injury.

A **DANGER** is only used when your action or lack of action may cause serious injury or even death.



IMPORTANT: Operator must be competent in the use of hydraulic equipment. The operator must have read and understood all instructions, safety issues, cautions and warnings before starting to operate the Equalizer equipment.



WARNING: Immediately replace worn or damaged parts with genuine Equalizer parts. Equalizer parts are designed to fit properly and withstand rated loads. For repair or maintenance service contact your Equalizer distributor or service centre.



WARNING: To avoid personal injury and possible equipment damage, make sure all hydraulic components are rated to a safe working pressure of 700 bar (10,000 psi)



DANGER: To avoid personal injury keep hands and feet away from the tool and workpiece during operation.



WARNING: Do not overload equipment. Overloading causes equipment failure and possible personal injury.



WARNING: Always wear suitable clothing and Personal Protective Equipment (PPE).

The risk of overloading can be avoided by using the Equalizer Hand Pump, which has its safety valve set to 700 bar by the factory. If alternative pumps are used, ensure they are rated at a safe working pressure of 700 bar (10,000 psi).



DANGER: Do not handle pressurised hoses. Escaping oil under pressure can penetrate the skin, causing serious injury. If oil is injected under the skin, seek medical attention immediately.



CAUTION: Make sure that all system components are protected from external sources of damage, such as excessive heat, flame, moving machine parts, sharp edges and corrosive chemicals.



WARNING: Never pressurize unconnected couplers. Only use hydraulic equipment in a connected system.



CAUTION: Avoid sharp bends and kinks that will cause severe back-up pressure in hoses. Bends and kinks lead to premature hose failure. Do not drop heavy objects onto hoses. A sharp impact may cause internal damage to hose wire strands; applying pressure to a damaged hose may cause it to rupture. Do not place heavy weights on the hoses, or allow vehicles to roll over the hoses; crush damage will lead to premature hose failure.



IMPORTANT: Do not lift hydraulic equipment by the hoses or couplers. Use the carrying handle or other means of safe transport.



CAUTION: Do not operate the equipment without lubricating all moving parts as in section 5.4, 6.4 & 7.4. Use only high pressure molybdenum disulphide grease.



3. TECHNICAL DATA

	Tool Description	Aligning Force
FA1TM	Mechanical Fixed Flange Alignment Tool	1.0 T (10kN)

3.1 KIT COMPONENTS

1 x FA1TM Tool

1 x Ratchet and Strap


1 x Instruction Manual



Product Code: FA1TMSTD

3.2 HOW THE FA1TM WORKS

- 1. The FA1TM is secured to the lower of the two flanges by fully inserting the lift hook into the bolt-hole at the point of greatest misalignment.
- 2. The drop leg thumb screw is slackened and the drop leg is adjusted down to the pipe while the tool is held level in the bolt-hole.
- 3. The drop leg thumb screw is then tighten until firm.





4. FLANGE MISALIGNMENT DETERMINATION PROCEDURE


The tool being used must not be attached to a flanged joint prior to the misalignment procedure being carried out.

4.1 LATERAL MISALIGNMENT

1. Loosen and remove every second bolt around the flange , continue with this until misalignment occurs.

A flanged joint, once broken down, may spring out of alignment at any point, or in any direction around its circumference. Misalignment may not occur until only a few bolts remain.

2. At this point the direction of any misalignment should become obvious. The alignment tool being used should be attached at the maximum point of misalignment (point A or B in the examples shown below) as shown in sections 5.3, 6.3 & 7.3.






5. FA1TM MECHANICAL FIXED FLANGE ALIGNMENT TOOL

5.1 INSTALLATION AND OPERATION

1. Carry out the Flange Misalignment
Determination Procedure (see
section 4) to determine the points
of maximum misalignment.


In this example the points of maximum misalignment are at the top and bottom of the joint.




2. Guide the lift hook into the bolt-hole at the point of maximum misalignment.

Adjust the drop leg down onto the pipe by slackening the thumb screw in a anticlockwise direction. The tool should be held up level within the bolt-hole during adjustment.

N.B. The tool must be parallel to pipe during operation.



3. Rotate the screw handle clockwise until then driven wedge makes contact with opposite flange.




4. Thread the strap through the aperture on the base of the drop leg as shown.





5. Feed the open end of the strap through the buckle mechanism as shown. Close the clasp to secure strap.




6. Now that everything is secured, rotate the handle clockwise to apply pressure to the circumference of the opposite flange and bring the flange joint in

alignment.



Do not exceed hand pressure on the screw handle





Care should be taken not to drop any of the component parts when removing them from the flange joint. This action will prevent injuries to either the operator's lower limbs, or to passers-by.



5.2 EXAMINATION AND STORAGE


- On return from each job and before allocation against subsequent work the completeness of the Equalizer FA1TM kit must be established and items examined to ensure that they are serviceable
- 2 Any missing or damaged items are to be replaced as soon as possible and prior to the tool being used again
- 3 Store the FA1TM in a cool dry place and ensure all machined surfaces are greased
- 4 Ensure wedges, pins and leg remain grit free and that parts move freely

5.3 MAINTENANCE

- 1 Secure the tool upright on a bench.
- 2 Using a small flat screw driver, lever out 1 Circlip and unscrew 5x 4mm hex screws.
- 3 Remove cover plate and remove any dirt or corrosion from moving parts
- Inspect components for wear and damage, replace if neccessary! If there is no damage present then they can be greased and re-assembled by reversing steps 1-4

Recommended grease -


Rocol Sapphire Hi-Load or equivalent good quality hi load bearing grease





5.4 PARTS LIST

NO.	PART NO	DESCRIPTION	QTY.
1	070280-01	BODY PLATE STICKER L	1
2	070281-01	BODY PLATE STICKER R	1
3	210100-01	DRIVING WEDGE	1
4	210200-01	BODY FRAME	1
5	210300-01	DRIVEN WEDGE	1
6	210400-01	DRIVE SCREW	1
7	210500-01	COVER PLATE	1
8	210501-01	COVER PLATE RIGHT	1
9	210600-01	CRANK HANDLE	1
10	210700-01	SPRING PIN	1
11	210800-01	TORSION SPRING	1
12	210900-01	NEEDLE BEARING	4
13	211100-01	BEARING SHAFT	4
14	211200-01	SPRING MANDREL	1
15	211300-01	M6X8 SCKT FL. SCREW	10
16	211600-01	DISTANCE PLATE	1
17	211800-01	DROP LEG	1
18	211900-01	LEG PIN 8MM	1
19	212000-01	SPRING RING 8MM	2
20	212200-01	LEG PLASTINC INSERT	1
21	230203-01	M6 RELEASE KNOB	1
22	771801-01	M6 HEX NUT	1
23	220800-01	RATCHET STRAP	1





5.5 WEIGHTS AND DIMENSIONS


WEIGHTS


Tool only = 1.6 kg (18.96 lbs)Ratchet & strap = 0.28 kg (0.62 lbs)

GROSS KIT WEIGHT = 8.88 kg (19.58 lbs)


DIMENSIONS


MINIMUM EXTENSION





MAXIMUM EXTENSION







5.6 TROUBLESHOOTING

Problem: The tool is attached and appears to be functioning properly, but the joint will not align

There may be something restricing the joint from aligning.

Check the area around the joint to establish if there is an obstruction

to the joint

The joint may require more than 1.0T (10 kN) force to align.


If the joint requires more force than that of the $4.0\ T\ (40kN)$ tool, attach a second tool or another method of aligning should be adopted.

5.7 APPLICATION DIMENSIONS

MINIMUM AND MAXIMUM FLANGE SIZES

Dimension A: must be between 14 and 82mm (0.55" and 3.29")

Dimension B: bolt-hole diameter must be 16 mm (0.63") or greater





CLASSE

NPS

2 -

2

122

ų.

12 3

4

Oi.

o.

7"

œ

9

6

12"

3

14"

3

6

7

18"

19"

20"

21"

22"

23"

24"

27"

29

30"

33

35

36"

39"

42"

45" 48"

TOOL

CLASS D

NPS

4

5

6

7"

00

9" 10"

12"

13"

14"

15"

16"

17"

18"

19"

20"

21"

22"

23"

24

29"

30"

33"

39"

42"

45"

48

54"

60

66"

72"

78"

84"

96"

108" 120"

TOOL

CLASSA

NPS

12 3

4:

6" 7"

œ

9:

0

12"

13"

14:

16"

16"

17"

8:

19"

20"

21"

22"

23"

24"

26"

27"

29"

30"

33"

36"

36"

39

42"

46:

48

54

60.

72"

TOOL

CLASS H

NPS

14

12.

Ŋ

122

ä

12

4

0

o.

7"

œ

ø

ō

12

3

14"

햐

6

17"

8

10

20

2

B

23"

24"

TOOL

NPS

12"

2

1/2"

မူ

1/2"

4

6"

6

7"

00

9

10"

12"

13"

14

16"

16"

17"

8

19"

20"

21"

22"

23"

24"

CLASSF

NPS

12.

2

1/2

3:

1/2"

4

ص: :

oj.

7"

00

9.

10"

12"

13"

14"

16:

16:

17"

8

19.

20"

21"

22"

23"

24"

27"

29"

30"

33

36

36

39

42"

45

48

TOOL

6.1 BS10 FLANGE RANGE OF APPLICATION

CL/	ASS K		ASS K	CL/	ASS K
TOOL	NPS	TOOL	NPS	TOOL	NPS
FA4TM		FA1TM	113-16" 21-16" 29-16" 318" 41-16" 51-8" 71-16"	FA	
MT	21-16"	MTI	21-16"	FA1TM	21-16"
	29-16"	FA4TM	2 9-16"		29-16"
FASTE	31-8"	1TM	31-8"	FA	318"
	41-16"		4 1-16"	FA4TM	41-16"
	51-8"	FASTE	6 1-8"		61-8"
	113-16" 21-16" 29-16" 31-8" 41-16" 51-8" 71-16"		7 1-16"		113-16" 21-16" 29-16" 31-8" 41-16" 51-8" 71-16"
	9		9"		9"
	11"		11"	FASTE	11"
	13 5-8"		13 5-8"		13 5-8"
	135-8" 163-4"		135-8" 163-4"		13 5-8" 16 3-4"

API6BX
WELD
NECK
WELD NECK FLANGE R
E RANG
RANGE OF APPLICATIO
PPLICA
NOIT
API6

5	ASS K	ASS K	2	ASS K	
1001	NPS	TOOL	NPS	TOOL	NPS
FAITM	NPS 21-16" 29-16" 31-8" 41-16" 51-8" 71-16"	FA1TM	NPS 21-16" 29-16" 31-8" 41-16" 51-8" 71-16"		NPS 21-16" 29-16" 31-8" 41-16" 51-8" 71-16"
TM	29-16"	TM	2 9-16"	FA1TM	29-16"
FA4TM	318"		318"		318"
MTI	41-16"	FA4TM	4 1-16"		41-16"
	51-8"		6 1-8"	FA4TM	518"
FASTE	7 1-16"		7 1-16"	ITM	7 1-16"
)TE	9"	FASTE	9"		9"
	11"	11"	11"		11"
	13 5-8"		13 5-8"		13 5-8"
	135-8" 163-4" 211-4"		135-8" 163-4" 211-4"		135-8" 1634" 2114"
	21 14"		21 1.4"		21 1.4"

API6B WELD NECK FLANGE RANGE OF APPLICATION

NPS 1/2" TOOL 1/2" NPS 1/2"	- 000	TOOL	NPS	TOOL						
12"		12" :		-		-				
3,4"		3/4"		1/4"		14"				
1		1		1/2"		1/2"				
1/4"		1/4"	FA1	2		2"	771			
2 -	71	12"	FA1TM 2" 2 3" 4" 5" 6" 7" 8" 9" 10" 12" 13" 14" 15" 16" 17" 18" 19" FA1TM FA1TM FA4TM FAATM F							
Nº	ATTM	2"		FA1TM FA1TM FA4TM FAATM FA						
2 1/2"		2 1/2"		1/2"	FA1TM FA4TM FAATM					
2 3" 3" 4" 4" 5" 6" FA4TM	3		4"		4"					
12"		1/2"		o.		5"				
4		4"				6"				
12"		1/2"	-A4TA	7"	_	6" 7" 8" 9" 10" 12"				
οį		8" 9" 10' 8" 9" 9" 9" 9" 9" 9" 9" 9" 9" 9" 9" 9" 9"	8"	_						
o _l	FA4TM	6"		9"	5	9"	FA4TM			
7"		7"		10"		10"				
81		8"		12"		12"				
9"		9"		13"						
10"					10"		14"		14"	
11"		11"	ĺ	16"		16"				
12"	FA9	12"	7	16"	17	16"				
13"	m	49TE	17"							
		14"		<u> </u>		18"				
		15"		19"		19"	F/			
		16"				20"	STE			
	1/2" 3/4" 1" 1/4" 1/2" 2" 1/2" 3" 1/2" 4" 4 5" 6" 7" 8"	FA31M 1/2" 3/4" 1" 1/4" 1/2" 2" 1/2" 3" 1/2" 4" 1/2" 5" 6" 7" 8" 9" 10" 11" 12"	1/2" 3/4" 1" 1/4" 1/2" 2" 1/2" 3" 1/2" 4" 1/2" 5" 6" 7" 8" 9" 10" 11" 12" 13" 14" 15" FA9TE	FA1TM FA4TM FAATM FA	112" 34" 1" 14" 12" 2" 12" 3" 12" 3" 12" 4" 6" 6" 7" 8" 9" 10" 12" 13" 14" 15" 16" 17" 18" 19" FATTM FATT	FATTM Table FATTM FAATTM FAAT	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			

CLASS T CLASS S CLASS R CLASS K CLASS J

SUITABLE FOR FA4TM TOO	SUITABLE FOR FA1TM TOOL
	SUITABLE FOR FA4TM TOOI

NOT SUITABLE FOR TOOLS



ASME B16.5 FLANGE RANGE OF APPLICATION

6.2

ASME B16.47 FLANGE RANGE OF APPLICATION

CLASS CLASS CLASS CLASS CLASS CLASS CLASS **T00L** TOOL TOOL 100F TOOL NPS 100L NPS NPS NPS NPS NPS 3/4" 34" 3/4" 3/4" 2 12 FAITM 3/4" 3/4" 3/4" 4 4 4 4 1/4" 1/4" 14 7 14 -1 1/4" 1/2" 1/4" 12 1/2" 1/4" 12" 12" N N Ŋ N FA1TM 1/2" N Ŋ 2 12" 1/2" 12" 2 1/2" 1/2 1/2 ů. ယူ ယူ ų. 1/2" 12" ų. ų. 3: 123 12" 4: 4 4 4 4 4 4 5 Oi. o. Oi. o. 5 o. o, 9 01 9 6 o. 6 ထူ 00 œ 00 œ œ œ ō 10" 10" ô 0 10" ô 12" 12 12" 12 12" 12" 12 14" 14 14" 14" 14" 4" 6 16" 16" 6. 16" 6 16" 18 18: 18" 18" 18" 8 18" 20" 20" 20" 20" 20" 20" 20" 24" 24" 24" 24" 24" 24" 24"

DIN WELD NECK FLANGE RANGE OF APPLICATION

	ASS 00		ASS DO		4.SS 00		ASS DO		ASS 50					
TOOL	NPS	TOOL	NPS	TOOL	NPS	TOOL	NPS	TOOL	NPS					
	22"		22"		22"		22"		22"					
FASTE	26"		26"		26"		26"		26"					
	28"	_	28"		28"	_	28"	FA	28.					
	30"	FA4TM	30"	FA4TM	30"	FA4TM	30"	FA4TM	30					
	32"	V	32"	4	32"	4	32"		32					
	34"		34"	34"	34"	34"		34"		34"		34		
	36"		36"		36"		36"		36					
	38"		38"		38"		38"		38"					
	40"		40" 42"			40"	40"	40"		40"		40"	NAME OF TAXABLE PARTY.	40"
	42"	FAS				FAS	42"	FAS	42"	FA9TE	42			
	44"	FA9TE	44"	FASTE	44"	FASTE	44"	100	44"					
	46"		46"		46"		46"		46					
	48		48"	1	48"		48:		48					

SUITABLE FOR FA1TM TOOL SUITABLE FOR FA1TM TOOL SUITABLE FOR FA1TE TOOL NOT SUITABLE FOR TOOLS				
1000 1000 1000	NOT SUITABLE FOR TOOLS	SUITABLE FOR FA19TE TOOL	SUITABLE FOR FA4TM TOOL	SUITABLE FOR FA1TM TOOL

CLASS

NPS

3/8"

12"

3/4"

-

112

2

1/2

ω.

4

0

6

7

00

10"

12"

TOOL

CLASS

NPS

3/4"

4

1 1/2"

2" 21/2"

ų.

4

ō

6

7"

œ.

0

12"

14"

TOOL

CLASS

NPS

3/4"

-

1 1/2"

2

212

ų.

4

o.

o.

7"

œ

10"

12"

14"

6"

CLASS

NPS

2

N

2 1/2

ω

4

oj.

oj.

7"

ø

ó.

12"

14"

6

8

20

TOOL

CLASS

NPS

1/2"

3/4"

-

1/4"1

12

2

1/2"

မူ

4

6

6

7"

œ

10"

12"

14"

16"

18

20"

24" 28"

32"

40

CLASS

12

N

2 1/2"

ų

4:

oj.

o.

7"

œ.

10"

12"

14"

히

18"

20"

24"

28"

32"

36"

40"

48"

56"

72" 80"

TOOL NPS



CL/ 150	ASS 000		ASS 000		ASS 00	CL/ 50	488 00		4 SS 00		ASS 000	CLA 90	4SS 00		ASS 00		ASS DO		A S S 50
TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLINPS	TOOL	TOOLWPS	TOOL	IOOLINES
	212		21/2		21/2		2 1/2		21/2		21/2		2 1/2		21/2		2 1/2'		7117
_	ų		ω		ωį		ų		٠ دې		ų		ų		ų		ų.		,
FA4TN	3 1/2		3 1/2"	FA	3 1/2		3 1/2"		3 1/2		3 1/2		3 1/2		3 1/2	3	3 1/2		177
2	4:		4.	FA4TM	4		4"	FA4TM	4		4.		4.		4.	30	4		-
	oj.		οį		οij		6,1	\$	o.	FA	Q.		6"		σį		6"		,
	o.	FA4TM	6		တူ	FA4TM	o.		۵i	FA4TM	e ⁱ		6		oj.		o _l		
	0	s	œ		œ	\$	00		00		œ _i		00		8		œ		19
	10"		10"		10"		10"		10"		10"		10"		10"		10"		3
	12"	2	12"		12"	8	12"	FA	12"		12"	FA4TM	12"		12"	FAITM	12"		1
	14"		14"	FASTE	14"		14"	FA9TE	14"		14"	MT	14"		14"	1TM	14"		1
	16"	FA9TE	16"		16"	FASTE	16"		16"		16"		16"	FA4TN	16"		16"		1
ı	18"	ET(18"		18"	ä	18"		18"		18"		18"	4	18"		18"		100
	20"		20"		20"		20"		20"		20"		20"		20"		20"		
	22"		22"		22"		22"		22"		22"		22"		22"		22"		
	24"		24"		24"		24"		24"		24"		24"		24"		24"	FAITM	1
										77	26"		26"		26"	FA4TM	26"	TM	3
										FASTE	28"		28"		28"		28"		1
			N 2								30"		30"		30"		30"		3
											32"	77	32"		32"		32"		,
											34"	FA9TE	34"	FA	34"		34"		
		2000	Survey.								36"		36"	FASTE	36"		36"		
NOT SUITABLE FOR	SUITABLE FOR FA19	SUITABLE FOR FA4	SUITABLE FOR FA1								38"		38"		38"		38"		1
UITAB	LEFC)LE FC	SLE FC								40"		40"		40"	FA9TE	40"	13	ŧ
LEFO	RFA	OR FA	OR FA								42"		42"		42"	Ti.	42"	FA4TM	1
묶	100	4	-	I											200	1			·

46"

44"

46"

42" 44"

46"

42" 44"

46"

42" 44"

46"